Datasheet M-Duino 50RRA+ WiFi & BLE





Technical Features CONECTABLE PLC ARDUINO 24Vcc M-DUINO

MODEL TYPE	M-Duino HF WiFi & BLE & GPRS	
Input Voltage	12 to 24Vdc (Fuse protection (2.5A) Polarity protection)	
Input rated voltage	24Vdc	
Rated Power	30 W	
I max.	1.5A	
Size	101x119.3x119.5	
Clock Speed	16MHz	
Flash Memory	256KB of which 8KB used by bootloader	
SRAM	8KB	
EEPROM	4KB	
Communications	12C, Ethernet, USB, RS485, RS232, SPI I (2x) Rx, Tx (Arduino pins), WiFi, BLE, GPRS, Max232-Max485-W5500	
USB consideration!	Only for uploading or debugging. NOT connected as a serial Cannot be working in a final application	

General Features

DC power supply	12 to 24Vdc
DC power supply	11.4 to 25.4Vdc
DC power supply	30 W MAX.
Power supply voltage	24Vdc
Power supply voltage	700Ma
Insulation resistance 20MΩ min.at 500Vdc between the AC terminals and the protective earth term	
ctric strength 2.300 VAC at 50/60 Hz for one minute with a leakage current of 10mA max. Between all the external AC terminals and the protective ground terminal.	
80m/s2 in the X, Y and Z 2 times each.	direction
0° to 60°C	
10% to 90% (no condensation)	
With no corrosive gas	
-20° to 60°C	
2ms min.	
597g max.	
	DC power supply DC power supply Power supply voltage Power supply voltage 20MΩ minat 500Vdc bet terminals and the protective 2300 VAC at 50/60 Hz (leakage current of 10mA r Between all the external A protective ground terminal 80m/s2 in the X, Y and Z 2 times each. 0° to 60°C 10% to 90% (no condensal With no corrosive gas -20° to 60°C

1 INPUTS (x22)

An/Dig Input 10bit (0-10Vcc) - (x12)


0 to 10Vac Input Impedance: 39K Separated PCB ground Rated Voltage: 10Vac 7 to 24Vdc I mim: 2 to 12 mA Galvanic Isolation

Digital Isolated Input

Expandability

I2C - 127 elements - Serial Port RS232/RS485

DIGITAL OUT DIGITAL/PWM OUT ANALOG OUT DIGITALIANALOG IN DIGITAL IN Rated Voltage: 24 Vdc ANALOGIDIGITAL CONFIGURATION SWITCH 7 to 24Vdc I min: 2 to 12 mA Galvanic Isolation Rated Voltage: 24 Vdc (24Vcc) - (x4) ARDUINO PIN ARDBOX FUNCTION 7 to 24Vdc I min: 2 to 12 mA Galvanic Isolation Interrupt isolated Input SWITCH CONF. HS (24Vcc) * - (x6) ISOLATED The Interrupt isolated Inputs can Rated Voltage: 24 Vdc lso work as Digital isolated Inputs



*Pins used for WiFi module



① OUTPUTS (x28)

0 to 10Vac I max: 20 mA Separated PCB ground Rated Voltage: 10Vac Analog Output 8bit (0-10Vcc) - (x8) The Analog outputs can 5 to 24Vdc Digital Isolated I max: 70 mA Galvanic Isolation Output (24Vcc) -(x4)Diode Protected for Relay Rated Voltage: 24Vdc 220V Vdc Digital Isolated I max: 5A Galvanic Isolation Output Relay - (x16) Diode protected for Relay lmax 24Vdc: 410 mA

PWM Isolated 5 to 24Vdc I max: 70 mA Galvanic Isolation Diode Protected for Relay Rated Voltage: 24Vdc Output 8bit (24Vcc) - (x8) The PWM outputs can also work as Digital outputs





Performance Specifications

Arduino Board	Arduino Mega 2560
Control method	Stored program method
I/O control method	Combination of the cyclic scan and immediate refresh processing methods.
Programming language	Arduino IDE. Based on wiring (Wiring is an Open Source electronics platform composed of a programming language. "similar to the C")
Microcontroller	ATmega2560
	http://arduino.cc/en/Tutorial/HomePage

Install Arduino IDE and the Industrial Shields boards

The steps to follow to install our equipment's to Arduino IDE are:

• Open the Arduino IDE, versión 1.8.0 or superior. If you don't have it yet, you can download here

https://www.arduino.cc/en/Main/Software.

- Press the "Preferences" option to "File" menu and open the preferences window.
- In the text box "Additional boards manager URLs", add the direction: http://apps.industrialshields.com/main/arduino/boards/package_industrialshields_index.json
- · Close the preferences window with the "OK" button.
- · Click on "Tools" menu, and open the "Boards" submenu, and click the "Boards Manager" option, to open the Boards Manager window.
- Search "industrialshields" to the search filter and select to the list and click "Install"
- Close the "Boards Manager". Once it is performed that steps, you are available to select each PLC that you wish to work on "Tools" -> "Boards": M-Duino...

To get more information:

https://www.industrialshields.com/first-steps-with-the-industrial-arduino-based-plc-s-and-the-panel-pc-s-raspberry-pi-based#boards

Warnings



Unused pins should not be connected. Ignoring the directive may damage the controller.

Before using this product, it is the responsibility of the user to read the product's User Guide and all accompanying documentation.

Industrial Shields PLCs must be powered between 12Vdc and 24Vdc. If a higher voltage is supplied to the equipment can suffer irreversible damage.

Maintenance must be performed by qualified personnel familiarized with the construction, operation, and hazards involved with the control.

Maintenance should be performed with the control out of operation and disconnected from all sources of power.

The Industrial Shields Family PLCs are Open Type Controllers. It is required that you install the M-Duino PLC in a housing, cabinet, or electric control room. Entry to the housing, cabinet, or electric control room should be limited to authorized personnel.

Inside the housting, cabinet or electric control room, the Industrial Shields PLC must be at a minimum distance from the rest of the components of a minimum of 25 cm, it can be severely damaged.

Failure to follow these installation requirements could result in severe personal injury and/or property damage. Always follow these requirements when installing M-Duino family PLCs.

In case of installation or maintenance of the M-Duino please follow the instructions marked in the Installation and Maintenance section on the User Guide

Do not disconnect equipment when a flammable or combustible atmosphere is present.

Disconnection of equipment when a flammable or combustible atmosphere is present may cause a fire or explosion which could result in death, serious injury and/or property damage.

Symbology

	Indicates that the equipment is suitable for direct current only; to identify relevant terminals
\sim	Indicates that the equipment is suitable for alternating current only; to identify relevant terminals
įД	To identify the control by which a pulse is started.
<u></u>	To identify an earth (ground) terminal in cases where neither the symbol 5018 nor 5019 is explicily required.
\otimes	To identify the switch by means of which the signal lamp(s) is (are) switched on or off.
C€	CE marking indicates that a product complies with applicable European Union regulations
\triangle	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury
4	To indicate hazards arising from dangerous voltages

Technical Support

You can contact with us using the best channel for you:



support@industrialshields.com



www.industrialshields.com



Visit our Blog, Forum orTicketing system



Use our chat service



Check the user guides



Visit our Channel

